

Clutch tips

- Use Hinson clutch plates in your clutch for the best performance.
- Soak your clutch plates before you install them.
- We recommend using petroleum based 80 weight Transmission oil
- Change the oil after each time you ride.
- Always maintain 1/8" to 1/4" of freeplay at the lever and perch.

Other parts available for this model

- HS589 momentum clutch basket
- H497 Inner hub/Pressure Plate
- FP154-8 CRF450R Fiber Clutch Plates
- SP165-7 CR250R, CRF450R Steel clutch Plates

Visit HinsonRacing.com for even more products for this bike

Warranty information

All merchandise manufactured by Hinson Clutch Components is guaranteed against defects in material and workmanship for a period of six months from the original date of purchase. Use of Kevlar and carbon fiber clutch plates will cause excessive wear and will void your warranty. Hinson Clutch Components will not warranty any product that has been modified, or where the product became defective due to improper installation, improper use, or any other misuse of the product. Hinson Clutch Components shall not be liable for any other damages caused by any defects in the product, whether incidental, consequential or otherwise. You must return the warranty card to validate your warranty. If your product is defective we will, at our discretion, repair or replace the product after it is returned to Hinson Clutch Components for a warranty inspection. Any request for warranty assistance will require your original receipt or acceptable proof of purchase. Hinson Clutch Components liability is limited to the cost of repair or replacement of the product. All warranty items will be viewed and acted upon at the discretion of Hinson Clutch Components.

Important! Warranty registration

Products must be registered in order to be eligible for warranty. Please log onto www.hinsonracing.com to activate your warranty registration. You will need to make note of your serial number, the small 8 digit number 180 degrees from Hinson Clutch Components on your part, as you cannot register your product without it.



2013-14 CRF450R COMPLETE KIT WITH SLIPPER CLUTCH



1. Remove basket

- Remove stock clutch cover and remove the o-ring gasket (this will be used with your new Hinson cover)
- Remove the pressure plate, springs and bolts, clutch stack and the inner hub and thrust washer and stock lock washer and washer behind lock washer (set these aside they will not be re used)
- Remove the basket from the bike




Figure 1



Figure 2




Figure 3

2. Remove Primary Gear

- Grind or center punch and drill the heads of the rivets off of the back of the basket to remove the stock retainer plate (see figure 1 and 2)
- Remove the primary drive gear and the stock cushions
- The stock basket and retainer plate will not be reused
- Your new Hinson clutch basket comes with a new kick starter gear already installed.

3. Install primary drive gear

- Install the primary drive gear and the cushions onto your new Hinson Basket with the recessed side up (Figure 3), use a lubricant such as WD-40 if necessary
- Clean the threads in the holes of the basket and the threads on the screws with contact cleaner or another suitable cleaner.
- Apply Red Loctite 272* generously to the cleaned screws and to the threads on the basket (Figure 4 and 5)
- Install the new retainer plate with the new 10X24-9/16" screws and tighten them to 3.3 ft/lbs (Figure 6)
- Using a hammer and punch, peen the screws where they come through the inside of the basket



Figure 4



Figure 5



Figure 6

4. Re-install basket into bike

- Re-install the basket and replace the oem thrust washer with the thrust washer provided with Hinson BTL589
- Install the Hinson BTL referring to the manual provided with it
- Tighten the main shaft nut to manufacturers specifications (Figure 7)
- Install your new Hinson clutch cover using the stock o-ring gasket




Figure 7

LOCTITE * It is crucial that you use RED Loctite #272. To insure proper bonding of the surfaces you need to clean the threads thoroughly with a contact cleaner, acetone, or another cleaning/degreasing solution. To make the bond even stronger you should use a Loctite primer. It is important that you use fresh Loctite since it has a shelf life. To ensure a permanent hold you need to put Loctite into the hole and also onto the screw. Keep in mind that you cannot use too much, you want complete coverage with the Loctite.